


Date	Rev.	Description





#### Instructions For Stripping Insulation:

1. Press the wire to be stripped into the wire stripper's slot, about 1" from the end. (Fig. A) Pull the wire down into the slot.
2. Push the wire stripper with the blade away from you to strip the insulation



#### Wrapping Wire:

1. Insert the stripped end of the wire into the tool's half moon-shaped hole on the edge of the tool and out through the groove in the tool. Insert until insulation bottoms out. (Fig.B)
2. Bend the wire over the tool and hold. (Fig.C)
3. Place the tool over the terminal or post and turn clockwise about 10 turns, to wrap the wire around the post. (Fig.D)



#### Unwrapping Wire:

1. To unwrap, place shortend of tool over post so wrapped wire seats in the end of the tool.
2. Turn tool counter-clockwise.

DCC. NO.
A4 DRAWING NO.

**GOLDSUN ELECTRONICS CO., LTD.**

PART NO. **GCP-030** Rev. **1**

Description :

UNIT mm	SCALE	SHEET 1 OF 1	CAS No: ERN No:
------------	-------	--------------	--------------------

DRAWN : Jay

VERIFY : Arthur / Sam