



UL62368-1



BS EN/EN62368-1



TPTC004



IEC62368-1



CB



CE



UKCA



■ Features


- Universal AC input / Full range
- Built-in active PFC function, PF>0.95
- High efficiency up to 94%
- Withstand 300VAC surge input for 5 seconds
- Up to 320% peak power capability
- Protections: Short circuit / Overload / Over voltage / Over temperature
- Built-in cooling fan ON-OFF control
- Current sharing up to 4000W (3+1)
- Built-in DC OK / remote ON-OFF / remote sense functions
- Standby power 5V@0.3A
- No load power consumption<0.85W (Note.6)
- 5 years warranty

■ Description

HRPG-1000N3 series is a 1000W single output AC/DC with ultra-hight peak power supply. This series operates for 90~264 VAC input voltage and offers models with different rated voltage ranging between 12 and 48 V that can satisfy the demands for all kinds of industrial equipments. Each model is cooled by the built-in fan with speed control, working for the temperature up to 70°C. Moreover, HRPG-1000N3 has various built-in functions such as auxiliary power, remote sense and remote on-off control, offering vast design flexibility for industrial application. It can provide 320% short-duration peak power for motor applications and electromechanical loads requiring much higher power during start-up.

■ Model Encoding

HRPG-1000N3-12



■ Applications

- Factory control or automation apparatus
- Test and measurement instrument
- Laser related machine
- Aging equipment
- RF application
- For inductive and capacitive load


■ GTIN CODE

 MW Search: <https://www.meanwell.com/serviceGTIN.aspx>


SPECIFICATION

MODEL	HRPG-1000N3-12	HRPG-1000N3-24	HRPG-1000N3-36	HRPG-1000N3-48			
OUTPUT	DC VOLTAGE	12V	24V	36V			
	RATED CURRENT	80A	42A	28A			
	CURRENT RANGE	0 ~ 80A	0 ~ 42A	0 ~ 28A			
	RATED POWER	960W	1008W	1008W			
	RIPLLE & NOISE (max.) Note.2	150mVp-p	200mVp-p	250mVp-p			
	VOLTAGE ADJ. RANGE	11 ~ 14V	22 ~ 28V	32 ~ 38V			
	VOLTAGE TOLERANCE Note.3	±2.0%	±1.0%	±1.0%			
	LINE REGULATION	±0.5%	±0.5%	±0.5%			
	LOAD REGULATION	±2.0%	±0.5%	±0.5%			
	SETUP, RISE TIME	1000ms, 50ms/230VAC	2000ms, 50ms/115VAC at full load				
INPUT	HOLD UP TIME (Typ.)	16ms/230VAC	16ms/115VAC at full load				
	VOLTAGE RANGE	90 ~ 264VAC(300VAC for 5 sec.)	127 ~ 370VDC				
	FREQUENCY RANGE	47 ~ 63Hz					
	POWER FACTOR (Typ.)	PF>0.95/230VAC	PF>0.99/115VAC at full load				
	EFFICIENCY (Typ.)	91.5%	93%	93%			
	AC CURRENT (Typ.)	8.5A/115VAC	5A/230VAC				
	INRUSH CURRENT (Typ.)	25A/115VAC	40A/230VAC				
PROTECTION	LEAKAGE CURRENT	<1.2mA / 240VAC					
	OVERLOAD Note.4	Output power >105% rated for more than 5 seconds then shut down o/p voltage, re-power on to recover					
		Output power > 320% rated then shut down o/p voltage, re-power on to recover for 12V					
		Output power > 350% rated then shut down o/p voltage, re-power on to recover for 24V, 36V and 48V					
FUNCTION	OVER VOLTAGE	14.5 ~ 16.5V	29 ~ 33V	39 ~ 46V	58 ~ 65V		
	OVER TEMPERATURE	Protection type : Shut down o/p voltage, re-power on to recover					
	CURRENT SHARING	Shut down o/p voltage, recovers automatically after temperature goes down					
	REMOTE ON-OFF CONTROL	Up to 4000W or (3+1) units. Please refer to the function manual.					
	REMOTE SENSE	Power ON : short; Power OFF : open. Please refer to the function manual.					
ENVIRONMENT	DC-OK SIGNAL	Compensate voltage drop on the load wiring up to 0.5V. Please refer to the function manual.					
	5V STANDBY	The TTL signal out, PSU turn on = 3.3 ~ 5.6V ; PSU turn off = 0 ~ 1V. Please refer to the function manual.					
	FAN CONTROL	5VSB : 5V@0.3A; tolerance ±5%, ripple : 50mVp-p(max.)					
	WORKING TEMP.	Fan on/off by NTC(RT50) or 30% load min.					
	WORKING HUMIDITY	-40 ~ +70°C (Refer to "Derating Curve")					
SAFETY & EMC	STORAGE TEMP., HUMIDITY	20 ~ 90% RH non-condensing					
	TEMP. COEFFICIENT	-40 ~ +85°C, 10 ~ 95% RH non-condensing					
	VIBRATION	±0.03%/°C (0 ~ 50°C)					
	SAFETY STANDARDS	10min./cycle, 60min. each along X, Y, Z axes					
	WITHSTAND VOLTAGE	UL62368-1, CAN/CSA C22.2 No. 62368-1, TUV BS EN/EN62368-1, AS/NZS62368.1, EAC TP TC 004 approved					
	ISOLATION RESISTANCE	I/P-O/P: 3kVAC I/P-FG: 2kVAC O/P-FG: 0.5kVAC					
	EMC EMISSION	I/P-O/P, I/P-FG, O/P-FG: 100M Ohms / 500VDC / 25°C / 70% RH		Parameter	Standard		
		Conducted		Test Level / Note			
		BS EN/EN55032 (CISPR32)		Class B			
		Radiated		BS EN/EN55032 (CISPR32)			
		Harmonic Current		Class A			
	EMC IMMUNITY	Voltage Flicker		BS EN/EN61000-3-3			
		BS EN/EN55035, BS EN/EN61000-6-2		-----			
		Parameter		Test Level / Note			
		ESD		ESD			
		BS EN/EN61000-4-2		Level 3, 8kV air ; Level 2, 4kV contact			
		Radiated		Level 3			
		EFT / Burst		BS EN/EN61000-4-4			
		Surge		Level 3			
		Conducted		BS EN/EN61000-4-5			
		Magnetic Field		Level 4			
OTHERS	Voltage Dips and Interruptions			>95% dip 0.5 periods, 30% dip 25 periods, >95% interruptions 250 periods			
	MTBF	1000W					
	DIMENSION	218*105*61.5mm (L*W*H)					
NOTE	PACKING	1.46Kg; 8pcs/12.8Kg/1.58CUFT					
	1. All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25°C of ambient temperature. 2. Ripple & noise are measured at 20MHz of bandwidth by using a 12" twisted pair-wire terminated with a 0.1uf & 47uf parallel capacitor. 3. Tolerance : includes set up tolerance, line regulation and load regulation. 4. After the output protection, restart the device about 30 seconds after the input disconnection interval. 5. Derating may be needed under low input voltages. Please check the derating curve for more details. 6. Length of set up time is measured at first cold start. Turning ON/OFF the power supply may lead to increase of the set up time. 7. No load power consumption<0.85W when RC+ & RC- (CN100 pin3,4) open. 8. The power supply is considered a component which will be installed into a final equipment. All the EMC tests are been executed by mounting the unit on a 360mm*700mm metal plate with 1mm of thickness. The final equipment must be re-confirmed that it still meets EMC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies." (as available on http://www.meanwell.com) 9. The ambient temperature derating of 3.5°C/1000m with fanless models and of 5°C/1000m with fan models for operating altitude higher than 2000m(6500ft). ※ Product Liability Disclaimer : For detailed information, please refer to https://www.meanwell.com/serviceDisclaimer.aspx						


■ Block Diagram



■ Derating Curve



■ Output Derating VS Input Voltage




■ Function Manual

1. Peak Power

$$P_{av} = \frac{P_{pk} \times t + P_{npk} \times (T-t)}{T} \leq P_{rated}$$

$$\text{Duty} = \frac{t}{T} \times 100\% \leq 35\%$$



P_{av} : Average output power (W)

P_{pk} : Peak output power (W)


P_{npk} : Non-peak output power (W)

P_{rated} : Rated output power (W)

t : Peak power width (sec)

T : Period (sec)

----- 100Vac
— 200Vac



For example (24V model) :

$V_{in} = 200V$ $\text{Duty}_{max} = 25\%$

$$P_{av} = P_{rated} = 1008W$$

$$P_{pk} = 2500W$$

$$t \leq 5 \text{ sec}$$

$$T \geq \frac{5 \text{ sec}}{25\%} \geq 20 \text{ sec}$$

$$P_{npk} \leq \frac{TP_{av} - tP_{pk}}{T-t}$$

$$P_{npk} \leq 511W$$

■ Function Description of CN100

Pin No.	Function	Description
1	AUXG	Auxiliary voltage output ground.
2	AUX	Auxiliary voltage output, 4.75~5.25V, referenced to pin 1(AUXG). The maximum load current is 0.3A. This output is not controlled by the "remote ON/OFF control".
3	RC+	Turns the output on and off by electrical or dry contact between pin 4 (RC-), Short: Power ON, Open: Power OFF.
4	RC-	Remote control ground.
5	CS	Current sharing signal. When units are connected in parallel, the CS pins of the units should be connected to allow current balance between units.
6,8	GND	This pin connects to the negative terminal(-V). Return for DC-OK signal output.
7	DC-OK	DC-OK signal is a TTL level signal, referenced to pin8(DC-OK GND). High when PSU turns on.
9	+S	Positive sensing. The +S signal should be connected to the positive terminal of the load. The +S and -S leads should be twisted in pair to minimize noise pick-up effect. The maximum line drop compensation is 0.5V.
10	-S	Negative sensing. The -S signal should be connected to the negative terminal of the load. The -S and +S leads should be twisted in pair to minimize noise pick-up effect. The maximum line drop compensation is 0.5V.

■ Function Manual

1. Remote Sense

The remote sensing compensates voltage drop on the load wiring up to 0.5V.




Fig 1.1

2. DC-OK Signal

DC-OK signal is a TTL level signal. High when PSU turns on.

Between DC-OK(pin7) and GND(pin6,8)	Output Status
3.3 ~ 5.6V	ON
0 ~ 1V	OFF




Fig 2.1

3. Remote ON-OFF Control

The PSU can be turned ON/OFF by using the "Remote Control" function.

Between RC+(pin3) and RC-(pin4)	Output Status
SW ON (Short)	ON
SW OFF (Open)	OFF




Fig 3.1

4. Current Sharing

HRPG-1000N3 has the built-in active current sharing function and can be connected in parallel, up to 4 units, to provide higher output power as exhibited below :

※ The power supplies should be paralleled using short and large diameter wiring and then connected to the load.

※ Difference of output voltages among parallel units should be less than 0.2V.

※ The total output current must not exceed the value determined by the following equation:

Maximum output current at parallel operation = (Rated current per unit) × (Number of unit) × 0.9

※ When the total output current is less than 5% of the total rated current, or say (5% of Rated current per unit) × (Number of unit) the current shared among units may not be fully balanced.





Fig 4.1

■ Mechanical Specification

Case No. 977H Unit:mm


 AC Input Terminal Pin No.
Assignment

Pin No.	Assignment
1	AC/L
2	AC/N
3	FG \pm

 DC Output Terminal Pin No.
Assignment

Pin No.	Assignment
1~3	+V
4~6	-V

Connector Pin No. Assignment(CN100) : HRS DF11-10DP-2DS or equivalent

Pin No.	Assignment	Pin No.	Assignment	Mating Housing	Terminal
1	AUXG	6,8	GND	HRS DF11-10DS or equivalent	HRS DF11-**SC or equivalent
2	AUX	7	DC-OK		
3	RC+	9	+S		
4	RC-	10	-S		
5	CS				

■ Installation Manual

 Please refer to : <http://www.meanwell.com/manual.html>